FROST

Install and quick-start guide

v1.2d
SNOWSKY Echo Mini

1 · Install

1. Charge the player and back up anything important on it.
2. Connect it to your computer by USB. It shows up as a disk.
3. Copy **`HIFIEC70.IMG`** to the top folder of the player's disk, then eject it safely and unplug.
4. On the player, hold **MENU** to open the main menu and choose **Install a firmware (.IMG)**.
5. Wait for the player to finish and restart. Do not unplug or power off while it writes.

Coming from stock firmware or something went wrong? Follow the loader route in **`FROST.md`** (USB loader mode). Your music and settings stay on the disk.

2 · Buttons

In the file browser

PLAY	Open
PLAY hold	Play everything in the folder
BACK	Up one folder
VOL− / VOL+	Move up / down
MENU hold	Main menu

On the play screen

PLAY	Play / pause
PLAY hold	Next track
BACK	Previous track
BACK hold	Change play mode
VOL− / VOL+	Volume
MENU	Switch screens

POWER: a short press turns the screen on or off; hold for 2–3 seconds to power off. Every button can be remapped in **Main menu › Buttons** or with a **`KEYMAP.TXT`** file.

3 · Make it yours

Theme: 24 looks, from Classic and Cassette to Neon, Matrix, Sakura and Green Hill.

Shuffle all music: every song on the card in a random order.

Audiobooks: bookmarks, m4b chapters and 30-second skips.

Equalizer: 10 bands, ±12 dB. Presets: Flat, Rock, Pop, Jazz, Classical, Bass boost, Vocal, Treble, Custom. Off means untouched audio.

Play modes (hold BACK): in order, repeat all, repeat one, shuffle, folders.

Sleep timer, **Brightness** (10 levels), **Sort files**, **Date and time**, **ReplayGain**.

4 · Your music

Put files on the internal disk or a microSD card (FAT32 or exFAT). Folders of any size work.

```
FLAC · WAV · AIFF · ALAC · APE · up to 192 kHz, bit-perfect
DSF / DFF up to DSD256 · played as 88.2 kHz / 24-bit
MP3 · AAC / M4A · Ogg Vorbis · Opus · Musepack · WMA 1/2
```

Tags are read from ID3, Vorbis, APE, MP4 and ASF, including Hebrew and other right-to-left text. Albums sort by track number. FROST remembers where you stopped and picks up there.

5 · Good to know

- **USB disk read/write** in the main menu lets your computer copy files while the player stays on.
- Both outputs work: 3.5 mm and 4.4 mm balanced.
- **Bluetooth**: Main menu › Bluetooth, turn it on, choose **Search for headphones** and press PLAY on yours. They reconnect by themselves next time.
- Stuck? Press the reset pin, then power on again. **Debug info** in the main menu shows details to share with us.