

START-UP INSTRUCTIONS – LOADING INSTRUCTIONS – SECURING THE LOADS

START-UP INSTRUCTIONS:

Turn the ignition to the first notch and wait until the high-pressure pump continues its cycle of building pressure. Once the high-pressure pump shuts off then you can start the pile driver. Prior to moving the pile driver increase the throttle in order to load the machine. ****MAKE SURE THERE IS ENOUGH DIESEL TO LOAD THE PILE DRIVER. IF THERE IS NOT ENOUGH THEN PLEASE PUT "CLEAR CLEAN DIESEL" in the tank.**** As you know they are limited to the amount of Diesel they are allowed to have in the machines while transporting in the container.

If it runs out of Diesel while loading, there is a process to get it fired up after "Clear Clean Diesel" is placed into the Diesel tank. You will need to turn the key to the first notch and let it build pressure, then you turn the key off and turn key back to the first notch again to let it build pressure. You will repeat this process 5x and the 6th time turn key to first notch and after it builds pressure and high-pressure pump shuts down then you will be able to continue to fire the machine.

LOADING INSTRUCTIONS:

The pile drivers should be loaded with the long "Mast" facing towards the cab of the truck. See photo attached. **Example Pic Only:** These machines do not have the GPS antenna bar installed on them.



SECURING THE LOADS:

There are 4-places on the undercarriage for the hooks and binder chains to be placed. 2 on each side. Pics of proper installation for transporting the GAYK Pile Drivers.

