PT. YONGJIN JAVASUKA GARMENT

INTRUKSI KERJA MESIN GELAR OTOMATIS SEMYEONG

WORK INTRUCTION OF SEMYEONG AUTOMATIC SPREADING MACHINE

Dokumen : YJ-IK.CUT.0019
Tgl .Efektif : 23 Desember 2020
No. Revisi : 00
Halaman : 1 dari 1

1



Perhatikan kontrol panel pada bagian sisi mesin kanan bawah .
Pay attention to the control panel on the lower right side of the machine

2



Nyalakan mesin dengan mengatur tombol pada posisi (ON) .
Start the engine by adjusting the button position (ON)

3



Tekan (MAIN SCREEN).
Press (MAIN SCREEN)

4



Putar tuas navigasi ke kiri/kanan untuk memindahkan mesin secara manual .
Turn the navigation lever left / right to move the machine manually

5



Tekan (set) untuk mengatur posisi awal dan akhir gelaran .
Press (set) to set the start and end position of the spreading

6



Tekan (lain piles).
Press (another piles)

7



Tekan present piles.
Press present piles

8



Putar kecepatan laju mesin .
Rotate the engine speed

9



Putar kecepatan mundur mesin
Turn the engine reverse speed

10



Putar akselesari turunnya bahan di awal gelaran sesuai material kain
Turn the acceration down of the start of spreading according to the fabric material

11



Putar tensi kontrol sesuai material kain
Turn the tension control according to the fabric material

12



Putar akselesari turunnya bahan di akhir gelaran sesuai material kain
Turn the acceration drop of the material at the end of spreading according to the fabric material

13



Tekan tombol start

Press the start button