PLANT 2 Maintenance Procedure	Case Packer Vacuum Pump Inspection		
	Document No.: **MP-502**	Revision: **A**	Effective: **2019-08-12**
Department: Maintenance	Prepared by: K. Petrov	Approved by: J. Brandt	

1.0 PURPOSE

Find a failing vacuum pump before it stops the case packer.

2.0 SCOPE

The vacuum pumps on CPK-1, CPK-2 and CPK-3. Monthly task in the maintenance system.

3.0 RESPONSIBILITIES

Role	Responsibility
Maintenance Technician	Carries out the inspection.
Maintenance Planner	Orders spare parts and schedules repairs.

4.0 SAFETY AND MATERIALS

Personal protective equipment: Safety glasses; Hearing protection; Safety shoes

Materials: Vacuum pump inlet filter; Bearing VP-BRG-6205

Tools: Infrared thermometer; Vacuum gauge; Stethoscope

5.0 RELATED DOCUMENTS AND RECORDS

Documents: SP-402 Lockout/Tagout, Rev B; WI-213 Case Packer Setup and Glue Check

Records: Maintenance work order

6.0 INSPECTION (PUMP RUNNING)

1. *Maintenance Technician:* Listen to the pump with the stethoscope at the drive end. Rumbling or grinding means a bearing is failing.
2. *Maintenance Technician:* Measure the bearing housing temperature. More than 70 degrees C, or more than 15 degrees above last month, is a fail.
3. *Maintenance Technician:* Read the vacuum at the pump inlet with the erector idle: at least 0.7 bar of vacuum.
4. *Maintenance Technician:* Write the three readings on the work order every month, pass or fail.

7.0 SERVICE (PUMP LOCKED OUT)

1. *Maintenance Technician:* Lock out the case packer using the group lock box, as described in SP-402, Rev B.

2. *Maintenance Technician:* Replace the inlet filter if it is dark or the vacuum reading was low.
3. *Maintenance Technician:* On a failed bearing check: replace bearing VP-BRG-6205 and check the coupling alignment.
4. *Maintenance Planner:* Keep at least one bearing VP-BRG-6205 in stores.

8.0 REVISION HISTORY

Rev	Date	Change
A	2019-08-12	First issue.