WORK INSTRUCTION	Filler Setup and Nozzle Check		WI-210 Rev D
PLANT 2	Dept: **Production**	Effective: **2023-04-03**	By: S. Lindqvist Appr: D. Whitfield

Purpose

Set up a rotary filler so that every nozzle fills inside the weight limits.

Scope

FIL-1, FIL-2 and FIL-3.

Roles

Role	Responsibility
Operator	Sets up and adjusts the filler.
Line Lead	Is told about any nozzle taken out of service.
Maintenance Technician	Repairs nozzles and valves.

PPE

- Safety glasses
- Chemical-resistant gloves
- Safety shoes

Tools

- Check scale (0.1 g)
- Nozzle wrench
- Sample tray

Materials

- Sanitizer

CAUTION: Never reach into the filler carousel while it is turning. Use the jog button with the guard closed.

Procedure

Setup

Step	Who	Action
1	Operator	Select the product recipe on the filler panel. Confirm the target weight on screen matches the table below.
2	Operator	Prime the bowl. Run two full rotations into the sample tray and discard.
3	Operator	Weigh one bottle from every nozzle (12 nozzles on FIL-1; all nozzles on FIL-2 and FIL-3). Write each weight on FRM-PR-10 Filler Setup Sheet.
4	Operator	Any nozzle more than 3 g from the others: stop, tell the Line Lead, and call the Maintenance Technician.

Adjustment during the run

Step	Who	Action

5	Operator	If the hourly average drifts from target, you may adjust the fill setpoint by up to 2 g up or down. Write the change and the time on FRM-PR-10.
6	Operator	If more than 2 g of adjustment is needed in one shift, stop adjusting and call the Maintenance Technician. Worn valve seals are the usual cause (see MP-501).
7	Operator	Dripping or stringing nozzle: wipe, run 10 bottles, check again. If it continues, take the nozzle out of service and tell the Line Lead.

Fill targets

Product	Target (g)	Lower limit (g)	Upper limit (g)
AC-1000 / AC-1000-LEM	1005	1000	1015
FS-2000	2010	2000	2030
FS-0500	504	500	512
DS-0750 / DS-0750-ECO	756	750	765

Related documents

- QP-303 Fill Weight Checks
- MP-501 Filler Lubrication and Valve Seal Inspection

Records

- FRM-PR-10 Filler Setup Sheet

Revision history

Rev	Date	Change
D	2023-04-03	Operators may adjust the setpoint by up to 2 g.
C	2022-06-13	Work-instruction template.