WORK INSTRUCTION	Capper Setup and Torque Check		WI-211 Rev C
PLANT 2	Dept: **Production**	Effective: **2022-11-07**	By: S. Lindqvist Appr: D. Whitfield

Purpose

Apply caps at the right torque so bottles neither leak nor are too hard to open.

Scope

CAP-1, CAP-2 and CAP-3.

Roles

Role	Responsibility
Operator	Sets up the capper and checks torque.
Maintenance Technician	Replaces chucks and adjusts clutches.

PPE

- Safety glasses
- Safety shoes

Tools

- Torque tester
- Chuck wrench

Materials

- Caps (28 mm)
- Caps (38 mm)

CAUTION: Cross-threaded caps mean the head height is wrong. Do not raise the torque to compensate.

Procedure

Setup

Step	Who	Action
1	Operator	Fill the cap hopper. Check the cap chute is free and the caps are the right size and colour for the product.
2	Operator	Set the head height so the chuck sits square on the cap with the bottle on the plate.
3	Operator	Set the application torque from the table below.

Torque check

Step	Who	Action
4	Operator	At start-up and every 2 hours: take one bottle from each capping head. Measure removal torque with the torque tester.
5	Operator	Write the values on FRM-PR-11 Torque Check Sheet.

6	Operator	One head out of range: adjust that head and re-check. Two or more heads out of range: stop the line and call the Maintenance Technician.
7	Operator	Product capped since the last good check goes on hold as described in QP-315.

Application torque

Cap	Used on	Torque (in-lb)	Tolerance
28 mm	Lines 1 and 3 (CAP-1, CAP-3)	12	plus or minus 2
38 mm	Line 2 (CAP-2), both bottle sizes	17	plus or minus 2

Related documents

- QP-315 Nonconforming Product and Hold

Records

- FRM-PR-11 Torque Check Sheet

Revision history

Rev	Date	Change
C	2022-11-07	38 mm torque raised from 15 to 17 in-lb after leak complaints.
B	2022-06-13	Work-instruction template.