WORK INSTRUCTION	Case Packer Setup and Glue Check		WI-213 Rev B
PLANT 2	Dept: **Production**	Effective: **2022-08-22**	By: S. Lindqvist Appr: D. Whitfield

Purpose

Erect, pack and seal shipper cases that survive the pallet.

Scope

CPK-1, CPK-2 and CPK-3.

Roles

Role	Responsibility
Operator	Sets up the case packer.
Maintenance Technician	Services the glue system and the vacuum pump.

PPE

- Safety glasses
- Heat-resistant gloves at the glue tank
- Safety shoes

Tools

- Infrared thermometer

Materials

- Shipper cases
- Hot-melt glue

CAUTION: Hot-melt glue causes deep burns. Do not open the tank lid without heat-resistant gloves.

Procedure

Setup

Step	Who	Action
1	Operator	Load the case magazine with the flaps facing the operator side. Do not mix case sizes.
2	Operator	Glue tank set to 175 degrees C. Wait for the ready light. Check the hose temperature with the infrared thermometer.
3	Operator	Check the vacuum gauge on the case erector reads at least 0.6 bar of vacuum with a case on the cups.
4	Operator	Run three cases. Check they are square and that all four flaps are glued.

During the run

Step	Who	Action

5	Operator	Every hour: tear open one sealed case. Fibre tear on both glue lines is a pass. Write it on FRM-PR-13 Case Seal Check.
6	Operator	Low vacuum or cases not erecting: check the cups for wear, then call the Maintenance Technician (see MP-502).
7	Operator	Never clear a jam with the machine running. For any work inside the guards, lock out as described in SP-402.

Related documents

- MP-502 Case Packer Vacuum Pump Inspection
- SP-402 Lockout/Tagout

Records

- FRM-PR-13 Case Seal Check

Revision history

Rev	Date	Change
B	2022-08-22	Vacuum check added.
A	2020-01-13	First issue.