Zone ID	Zone	Upstream PD	Downstream	Max	Fault	Reference	Coordination	Amp Range		Condition
Zone ID	Type		PD	Type	Amp	kV	Status	From	То	Condition
Bus6	Bus	CB4	CB5	3Ph	13094	0.48	Pass	125.2	2678	Devices are coordinated between amp range of 125.2 A to 2678A @ 0.48 kV
				L-G	12353	0.48	Pass	125.2	2678	Devices are coordinated between amp range of 125.2 A to 2678A @ 0.48 kV
			CB16	3Ph	13087	0.48	Pass	28.1	991.5	Devices are coordinated between amp range of 28.1 A to 991.5A @ 0.48 kV
				L-G	12353	0.48	Pass	28.1	991.9	Devices are coordinated between amp range of 28.1 A to 991.9A @ 0.48 kV
			CB6	3Ph	13094	0.48	Pass	309.9	7028	Devices are coordinated between amp range of 309.9 A to 7028A @ 0.48 kV
				L-G	12353	0.48	Pass	309.9	7028	Devices are coordinated between amp range of 309.9 A to 7028A @ 0.48 kV
			CB7	3Ph	13094	0.48	Pass	309.9	7028	Devices are coordinated between amp range of 309.9 A to 7028A @ 0.48 kV
				L-G	12353	0.48	Pass	309.9	7028	Devices are coordinated between amp range of 309.9 A to 7028A @ 0.48 kV
			CB8	3Ph	12339	0.48	Pass	309.9	7028	Devices are coordinated between amp range of 309.9 A to 7028A @ 0.48 kV