

Rusty Timer Forwarder Reference

Forwarder ID: _____ Ethernet IP: _____

Hostname UI:

http:// _____ .local/

Ethernet IP UI:

http:// _____ /

Ethernet note: The static IP works only when your computer is connected by Ethernet to the forwarder network. It will not work over Wi-Fi or hotspot.

Device	Turn on	Turn off
Android hotspot	1. Plug phone into power. 2. Hold lock/power button to turn on. 3. Unlock phone. 4. Open Settings → Network & internet → Hotspot & tethering. 5. Turn on Wi-Fi hotspot. 6. Keep phone plugged in and near forwarder.	1. Unlock phone. 2. Swipe down from top twice. 3. Tap power icon. 4. Tap Power off. If no power icon: press Power + Volume Up, then tap Power off. Note: Holding only the power button may open Assistant/Gemini.
Forwarder	1. Make sure hotspot is on. 2. Connect power to forwarder. 3. Pi should turn on automatically; case fan should start. 4. If fan does not start, use small red button on side of Pi case: • Short press once, then press and hold until fan turns on. 5. Ready when LCD screen shows status. 6. Open UI and confirm Ready and reader Connected.	Preferred: In UI, go to Config → Dangerous Actions and choose Shutdown Forwarder Device. Wait for fan to stop. If the button is greyed out, enable and save Allow restart/shutdown actions in Forwarder Controls. Without UI: Use small red button on side of Pi case. Short press once, then press and hold until shutdown starts. Wait for fan to stop.

Important: Unplugging the forwarder does not turn it off. The forwarder has UPS backup power. Use the UI or the button to shut it down safely.

Other operations

- **Readers:** Reader IPs can change. Check or update them in **Config** → **Readers**. After saving reader changes, restart the forwarder service if the UI says a restart is needed.
- **Advance epoch:** In the forwarder UI, open the reader panel and use **Advance Epoch**.

Rusty Timer Forwarder Reference

Forwarder ID: _____ Ethernet IP: _____

Hostname UI:

http:// _____ .local/

Ethernet IP UI:

http:// _____ /

Ethernet note: The static IP works only when your computer is connected by Ethernet to the forwarder network. It will not work over Wi-Fi or hotspot.

Device	Turn on	Turn off
Android hotspot	1. Plug phone into power. 2. Hold lock/power button to turn on. 3. Unlock phone. 4. Open Settings → Network & internet → Hotspot & tethering. 5. Turn on Wi-Fi hotspot. 6. Keep phone plugged in and near forwarder.	1. Unlock phone. 2. Swipe down from top twice. 3. Tap power icon. 4. Tap Power off. If no power icon: press Power + Volume Up, then tap Power off. Note: Holding only the power button may open Assistant/Gemini.
Forwarder	1. Make sure hotspot is on. 2. Connect power to forwarder. 3. Pi should turn on automatically; case fan should start. 4. If fan does not start, use small red button on side of Pi case: • Short press once, then press and hold until fan turns on. 5. Ready when LCD screen shows status. 6. Open UI and confirm Ready and reader Connected.	Preferred: In UI, go to Config → Dangerous Actions and choose Shutdown Forwarder Device. Wait for fan to stop. If the button is greyed out, enable and save Allow restart/shutdown actions in Forwarder Controls. Without UI: Use small red button on side of Pi case. Short press once, then press and hold until shutdown starts. Wait for fan to stop.

Important: Unplugging the forwarder does not turn it off. The forwarder has UPS backup power. Use the UI or the button to shut it down safely.

Other operations

- **Readers:** Reader IPs can change. Check or update them in **Config** → **Readers**. After saving reader changes, restart the forwarder service if the UI says a restart is needed.
- **Advance epoch:** In the forwarder UI, open the reader panel and use **Advance Epoch**.