





### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### (i) Important!

This replacement procedure can be used for:

BMW 3 Compact (E46) 316ti 1.8, BMW 3 Compact (E46) 325ti 2.5, BMW 3 Compact (E46) 318ti 2.0, BMW 3 Compact (E46) 320td 2.0, BMW 3 Compact (E46) 318td 2.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Touring (E46) 320d 2.0

CLUB.AUTODOC.CO.UK 1–9





# REPLACEMENT: BRAKE PAD WEAR SENSOR – BMW 3 COMPACT (E46). TOOLS YOU'LL NEED:



- Wire brush
- Brake cleaner
- Electronic spray
- Copper grease

- Torque wrench
- Wheel impact socket #17
- Round-nose pliers
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-9





# Replacement: brake pad wear sensor – BMW 3 Compact (E46). AUTODOC experts recommend:

- The replacement procedure is identical for both brake pad wear sensors on the same axle.
- Please note: all work on the car BMW 3 Compact (E46) should be done with the engine switched off.

### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- Open the bonnet. Unscrew the brake fluid reservoir cap.
- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Lift the car using a jack or place it over an inspection pit.
- 5 Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 3–9







#### AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. BMW 3 Compact (E46)





Remove the brake pad wear sensor from the brake pad. Use round-nose pliers.



- Disconnect the brake pad wear sensor wire. 8
- Open the cover of the wiring housing.



CLUB.AUTODOC.CO.UK 4-9







Detach the connector of the brake pad wear sensor.



Install the wear sensor on the brake pads. Use round-nose pliers.



Connect the brake pad wear sensor wire.



Treat the brake pad wear sensor plug. Use dielectric grease.



Attach the connector of the brake pad wear sensor.

14



CLUB.AUTODOC.CO.UK 5-9







Close the wiring housing cover.



Clean the wheel rim mounting seat. Use a wire brush.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.

18



#### **AUTODOC** recommends:

• Replacement: brake pad wear sensor – BMW 3 Compact (E46). After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 6–9







19 Install the wheel.



#### **AUTODOC** recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW 3 Compact (E46)
- Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



CLUB.AUTODOC.CO.UK 7–9







Remove the jacks and chocks.



Tighten the brake fluid reservoir cap. Close the hood.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 8-9