


VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Saloon (E90) 325i 2.5, BMW 3 Saloon (E90) 330i 3.0, BMW 1 Hatchback (E81) 130i 3.0, BMW 3 Touring (E91) 325i 2.5, BMW 3 Touring (E91) 330i 3.0, BMW 3 Saloon (E90) 325xi 2.5, BMW 3 Saloon (E90) 330xi 3.0, BMW 3 Touring (E91) 325xi 2.5, BMW 3 Touring (E91) 330xi 3.0, BMW 3 Coupe (E92) 325i 2.5, BMW 3 Coupe (E92) 330xi 3.0, BMW 3 Coupe (E92) 330xi 3.0, BMW 3 Coupe (E92) 325xi 2.5, BMW 3 Coupe (E92) 330xi 3.0, BMW 3 Coupe (E92) 325xi 2.5, BMW 3 Coupe

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–9







REPLACEMENT: AIR FILTER – BMW E82. TOOLS YOU MIGHT NEED:



- Torx bit T25
- Ratchet wrench
- Flat Screwdriver

- Microfibre towel
- Fender cover

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-9



0

AUTODOC recommends:

- Replacement: air filter BMW E82. Do not ignore the maintenance schedule, recommendations, and requirements specified by the manufacturer on the use of the car part.
- All work should be done with the engine stopped.

REPLACEMENT: AIR FILTER – BMW E82. RECOMMENDED SEQUENCE OF STEPS:

Open the bonnet.

2

3



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Undo the fastening screws of the air filter cover. Use Torx T25. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 3–9







Take off the filter lid.



Detach the air duct housing from the air filter housing. Use a flat screwdriver.



Remove the filter element from the filter housing.



Cover the air intake hose with a microfibre towel to prevent dust and dirt from getting into the system.



CLUB.AUTODOC.CO.UK 4–9







8 Clean the air filter cover and housing.



Replacement: air filter – BMW E82. Tip from AUTODOC experts:

- Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.
- Remove the microfibre towel from the air intake hose.



Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



10

CLUB.AUTODOC.CO.UK 5–9





Replacement: air filter – BMW E82. Tip:

- Check out the correct location of the filter element. Do not skew.
- Attention! Use quality filters BMW E82.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.
- 11 Install the air duct housing.



Reinstall the air filter cover. Fasten it.

13



Screw in the fastening screws of the air filter cover. Use Torx T25. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 6-9







Remove the fender protection cover.




Close the hood.






VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 7-9





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

AIR FILTER: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 8-9