





### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### (i) Important!

This replacement procedure can be used for:

BMW 1 Convertible (E88) 120i 2.0, BMW 1 Convertible (E88) 125i 3.0, BMW 1 Convertible (E88) 118i 2.0, BMW 1 Convertible (E88) 135i 3.0, BMW 1 Convertible (E88) 120d 2.0, BMW 1 Convertible (E88) 118d 2.0, BMW 1 Convertible (E88) 123d 2.0, BMW 1 Convertible (E88) 128i 3.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E90) 318i 2.0

CLUB.AUTODOC.CO.UK 1–12







# REPLACEMENT: WHEEL BEARING – BMW 1 CONVERTIBLE (E88). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Sealant
- Combination spanner #18
- Drive socket # 18
- HEX bit no.H6.

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Tap wrench
- Crow bar
- Rubber mallet
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-12







#### AUTODOC recommends:

- Do not re-use the bearing assembly of your BMW 1 Convertible (E88) car.
- The wheel hub bearing replacement procedure is identical for both wheels on the same axle.
- All work should be done with the engine stopped.

# REPLACEMENT: WHEEL BEARING – BMW 1 CONVERTIBLE (E88). RECOMMENDED SEQUENCE OF STEPS:

1 Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-12







4 Unscrew the wheel bolts.



### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
  BMW 1 Convertible (E88)
- Remove the wheel.



- 6 Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench. Use a ratchet wrench.



Remove the fastening bolts (2 pieces).

CLUB.AUTODOC.CO.UK 4-12







Spread the brake pads. Use a crowbar.

10



Remove the brake caliper together with its bracket.



### Replacement: wheel bearing – BMW 1 Convertible (E88). Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.

CLUB.AUTODOC.CO.UK 5-12







Unscrew the brake disc fastening. Use HEX No.H6. Use a ratchet wrench.



Remove the brake disc.



- Clean the wheel hub fastener. Use a wire brush. Use WD-40 spray.
- Unscrew the wheel hub axle nut. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



- 16 Remove the fastening bolts.
- Remove the hub and the bearing together, since they are a sealed unit.



CLUB.AUTODOC.CO.UK 6-12







## Replacement: wheel bearing – BMW 1 Convertible (E88). AUTODOC experts recommend:

• If necessary, use a rubber mallet.





- Treat the fastening bolts. Use a sealant.
- Install the new wheel hub with a bearing.



- Install the fastening bolts.
- Tighten the hub. Use a combination spanner #18. Use a torque wrench. Tighten it to 110 nm torque.



CLUB.AUTODOC.CO.UK 7-12







### AUTODOC recommends:

• Important! Be sure to use new fasteners.





24 Install the brake disc.



Tighten the brake disc fastening. Use HEX No.H6. Use a torque wrench. Tighten it to 16 Nm torque.



Treat the fastening bolts. Use a sealant.

CLUB.AUTODOC.CO.UK 8-12







Clean the mounting seats of the caliper and its bracket. Use a wire brush. Use WD-40 spray.



Install the brake caliper together with its bracket.



- 29 Install the fastening bolts (2 pieces).
- Tighten the brake caliper bracket. Use a drive socket #18. Use a torque wrench. Tighten it to 110 Nm torque.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



CLUB.AUTODOC.CO.UK 9-12







Clean the brake disk surface. Use a brake cleaner.



### AUTODOC recommends:

• Replacement: wheel bearing – BMW 1 Convertible (E88). After applying the spray, wait a few minutes.

33

Install the wheel.



### AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW 1 Convertible (E88)

34

Screw in the wheel bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 10-12