






SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 3 Coupe (E36) 318is 1.8, BMW 3 Coupe (E36) 320i 2.0, BMW 3 Coupe (E36) 325i 2.5, BMW 3 Coupe (E36) 316i 1.6, BMW 3 Coupe (E36) M3 3.0, BMW 3 Coupe (E36) 328i 2.8, BMW 3 Coupe (E36) 318is 1.9, BMW 3 Coupe (E36) 323i 2.5, BMW 3 Coupe (E36) M3 3.2, BMW 3 Coupe (E36) 325is 2.5

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E36) 323i 2.5


CLUB.AUTODOC.CO.UK 1–10







REPLACEMENT: ANTI ROLL BAR LINKS – BMW 3 COUPE (E36). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #13
- Combination spanner #16
- Combination spanner #17

- Drive socket # 13
- Drive socket # 16
- Drive socket # 17
- Wheel impact socket #17
- Ratchet wrench
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-10







AUTODOC recommends:

- Replace the stabiliser links on BMW 3 Coupe (E36) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Please note: all work on the car BMW 3 Coupe (E36) should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- 1 Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the front of the car and secure on supports.
- 4. Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 3-10







AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
BMW 3 Coupe (E36)





Clean all joints of the stabiliser link. Use a wire brush. Use WD-40 spray.



Unscrew the fastener connecting the stabilizer bar with the control arm. Use a combination spanner #13. Use a drive socket #13. Use a ratchet wrench.



Remove the fastening bolt.



CLUB.AUTODOC.CO.UK 4-10







Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.



10 Remove the stabilizer rod.

11



Replacement: anti roll bar links – BMW 3 Coupe (E36). AUTODOC experts recommend:

• Examine the stabiliser bushes. Replace them if necessary.

Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 5-10







12 Install the transverse stabilizer link.



- 13 Install the fastening bolt.
- Tighten the stabiliser link fastener. Use a combination spanner #17. Use a drive socket #17. Use a ratchet wrench.



Support the arm. Use a hydraulic transmission jack.



Tighten the fastener connecting the stabilizer bar with the control arm. Use a combination spanner #17. Use a drive socket #17. Use a torque wrench. Tighten it to 42 Nm torque.



CLUB.AUTODOC.CO.UK 6-10







Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use a drive socket #17. Use a torque wrench. Tighten it to 59 Nm torque.



18 Remove the support from under the arm.



AUTODOC recommends:

- Replacement: anti roll bar links BMW 3 Coupe (E36). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.
- Treat all joints of the stabiliser link. Use copper grease.



CLUB.AUTODOC.CO.UK 7-10








Clean the wheel rim mounting seat. Use a wire brush.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

• Replacement: anti roll bar links – BMW 3 Coupe (E36). After applying the spray, wait a few minutes.

23

Install the wheel.



CLUB.AUTODOC.CO.UK 8-10







AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW 3 Coupe (E36)





Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



Remove the jacks and chocks.

26





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 9-10