

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: BMW 3 Convertible (E93) 318i 2.0, BMW 3 Convertible (E93) 320i 2.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Convertible (E46) 318Ci 2.0

CLUB.AUTODOC.CO.UK 1–12





REPLACEMENT: ENGINE OIL AND FILTER – BMW 3 CONVERTIBLE (E93) CONVERTIBLE. TOOLS YOU MIGHT NEED:



- All-purpose cleaning spray
- Oil filter cup socket 86/16 F
- Drive socket # 17
- Ratchet wrench
- Torque wrench

- Flat Screwdriver
- Funnel
- Oil drain pan
- Microfibre towel
- Fender cover

Buy tools

CLUB.AUTODOC.CO.UK 2-12





AUTODOC recommends:

- Replace the oil filter every time when changing motor oil.
- Please note: all work on the car BMW 3 Convertible (E93) convertible should be done with the engine switched off.
- Wear gloves to prevent contact with hot liquid.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- 1 Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Unscrew the oil filler plug.



Lift the car using a jack or place it over an inspection pit.

Replacement: engine oil and filter – BMW 3 Convertible (E93) convertible. Tip:

• The vehicle must be on even keel, and if it is at an angle, the drain plug must be at the lowest point.

CLUB.AUTODOC.CO.UK 3-12







Put a waste oil container with at least 6 l capacity under the drainage hole.



Unscrew the drain plug. Use a drive socket #17. Use a ratchet wrench.



7 Drain the used oil.



Replacement: engine oil and filter – BMW 3 Convertible (E93) convertible. Tip from AUTODOC:

• Caution! The oil may be hot.

Unscrew the oil filter. Use the 86/16 F socket.



CLUB.AUTODOC.CO.UK 4–12







9 Remove the oil filter.

11



Prepare a container for the old oil filter. Put the old oil filter in the container.



Replacement: engine oil and filter – BMW 3 Convertible (E93) convertible. AUTODOC experts recommend:

• Move up the container. The oil starts to drain out of the drainage hole immediately after you have removed the oil filter.

Cover the oil filter housing with a microfibre towel to prevent dirt and foreign objects from getting into the system.



CLUB.AUTODOC.CO.UK 5-12



Detach the oil filter from the filter cover.



Remove old o-rings from the oil filter cover. Use a flat screwdriver.



Clean the oil filter housing cap. Use all-purpose cleaning spray.



Install new O-rings and a new oil filter to their mounting seats on the filter cover.



Please note!

• Make sure to install the filter correctly. Don't mix up the sides of the part.

CLUB.AUTODOC.CO.UK 6-12







Remove the microfibre towel from the oil filter housing.



17 Clean the oil filter seat.



Lubricate the rubber seal of the new filter with a little amount of fresh oil.



Screw the new filter into its place.

20



Screw the cap. Use the 86/16 F socket. Use a torque wrench. Tighten it to 25 Nm torque.



CLUB.AUTODOC.CO.UK 7-12



Replacement: engine oil and filter – BMW 3 Convertible (E93) convertible. Tip from AUTODOC experts:

• Wait until the oil has completely drained from the drainage hole.

Clean the area of the oil pan drainage hole.



Screw in the new drainage plug and tighten it. Use a drive socket #17. Use a torque wrench. Tighten it to 25 Nm torque.



Clean the area of the oil pan drainage hole. Use all-purpose cleaning spray.



Lower the car.

CLUB.AUTODOC.CO.UK 8-12







Remove the oil filler cap. Insert the funnel.



Pour new oil into the engine in the amount recommended by the car manufacturer.



Replacement: engine oil and filter – BMW 3 Convertible (E93) convertible. Professionals recommend:

- Use the oil recommended by the manufacturer.
- Check the oil level using the dipstick. Top up oil if necessary.



Please note!

• The oil level should be between the Min and Max marks.

CLUB.AUTODOC.CO.UK 9-12







Tighten the oil filler cap.



- Run the engine for a few minutes. After the oil pressure warning light goes out, stop the engine.
- Check the oil level 5 minutes after the stop of the engine operation using a dipstick and add oil if necessary.



Please note!

- The oil level should be between the Min and Max marks.
- Make sure that the oil filler cap is properly tightened.
- Check the threaded plug of the drainage hole and the oil filter seal for tightness. If necessary, carefully tighten them up.
- Remove the fender protection cover.
- Close the hood.

CLUB.AUTODOC.CO.UK 10-12