

Heating and Ventilation



The heating and ventilation system:

- controls the temperature and, during A/C operation, reduces the relative humidity of the air inside the vehicle.
- delivers heated or cooled air to maintain the vehicle interior temperature and comfort level.

Heater Core

The heater core consists of fins and tubes arranged to extract heat from the engine coolant and transfer it to air passing through the heater core.

Blower Motor

The blower motor pulls air from the air inlet and forces it into the heater core and evaporator core housing and the plenum chamber where it is mixed and distributed.

Heater Core and Evaporator Core Housing

The heater core and evaporator core housing directs airflow from the blower motor through the evaporator core and heater core. All airflow from the blower motor passes through the evaporator core. The airflow is then directed through or around the heater core by the temperature blend door. After passing through the heater core, the airflow is distributed to the selected outlet by the airflow mode doors.