

# Diagnostic Trouble Code (DTC) Chart



**NOTE:** The Body Control Module (BCM) utilizes a 5-character DTC followed by a 2-character failure-type code. The failure-type code provides information about specific fault conditions such as opens or shorts to ground. Continuous Memory Diagnostic Trouble Codes (CMDTCs) have an additional 2-character DTC status code suffix to assist in determining DTC history.

| DTC      | Description                                                      | Source          | Action                                                                                           |
|----------|------------------------------------------------------------------|-----------------|--------------------------------------------------------------------------------------------------|
| P0562    | System Voltage Low                                               | PCM             | GO to Pinpoint Test B.                                                                           |
| P0563    | System Voltage High                                              | Various Modules | GO to Pinpoint Test A.                                                                           |
| P0620    | Generator Control Circuit                                        | PCM             | GO to Pinpoint Test C.                                                                           |
| P0625    | Generator Field Terminal Circuit Low                             | PCM             | GO to Pinpoint Test D.                                                                           |
| P0626    | Generator Field Terminal Circuit High                            | PCM             | GO to Pinpoint Test D.                                                                           |
| P065B    | Generator Control Circuit Range/Performance                      | PCM             | GO to Pinpoint Test E.                                                                           |
| P0A5A    | Generator Current Sensor Circuit Range/Performance               | PCM             | GO to Pinpoint Test H.                                                                           |
| P0A5B    | Generator Current Sensor Circuit Low                             | PCM             | GO to Pinpoint Test H.                                                                           |
| P0A5C    | Generator Current Sensor Circuit High                            | PCM             | GO to Pinpoint Test H.                                                                           |
| P1397    | System Voltage Out Of Self-Test Range                            | PCM             | If combined with P0562, GO to Pinpoint Test B.<br>If combined with P0563, GO to Pinpoint Test A. |
| B1317    | Battery Voltage High                                             | Various Modules | GO to Pinpoint Test A.                                                                           |
| B1318    | Battery Voltage Low                                              | Various Modules | GO to Pinpoint Test B.                                                                           |
| B1676    | Battery Pack Voltage Out of Range                                | Various Modules | If combined with B1317, GO to Pinpoint Test A. If combined with B1318, GO to Pinpoint Test B.    |
| U1007:31 | Lost Communication With Battery Monitoring Sensor "A": No Signal | BCM             | GO to Pinpoint Test I.                                                                           |
| U3003:16 | Battery Voltage: Circuit Voltage Below Threshold                 | Various Modules | GO to Pinpoint Test B.                                                                           |
| U3003:17 | Battery Voltage: Circuit Voltage Above Threshold                 | Various Modules | GO to Pinpoint Test A.                                                                           |

| DTC            | Description | Source          | Action                                                                                                                                                 |
|----------------|-------------|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| All other DTCs | —           | Various Modules | REFER to Section 419-10 or the PCM DTC Chart in Section 303-14. If directed to this section from another section, GO to Symptom Chart in this section. |