

Symptom Chart



Symptom Chart

Condition	Possible Causes	Action
System voltage high	- Fuse - Wiring, terminals or connectors - Engine, generator and battery grounds - Battery - Generator - PCM	GO to Pinpoint Test A.
System voltage low or battery is discharged	- Fuse - Fusible link - Wiring, terminals or connectors - Engine, generator and battery grounds - Abnormal ignition-off current drain(s) - Radial arm adapter - Battery - Generator - PCM	GO to Pinpoint Test B.
The generator is noisy	- Front End Accessory Drive (FEAD) belt - Loose bolts/brackets - Generator/pulleys	GO to Pinpoint Test F.
Radio interference	Generator	GO to Pinpoint Test G.

	• Wiring, terminals or connectors • In-vehicle entertainment system	
• Charging system warning indicator is never/always on	• Instrument Panel Cluster (IPC) • Generator • PCM • Wiring, terminals or connectors	• RETRIEVE Continuous Memory Diagnostic Trouble Codes (CMDTCs) from all modules. If any charging system DTCs are found, REFER to the Diagnostic Trouble Code (DTC) Chart in this section. If no charging system DTCs are found, REFER to Section 413-01.
• Load Shed Message Displays in message center and/or centerstack infotainment display	• Normal operation • Audio system • Battery • BCM • Fuses or fusible links • Generator • Wiring, terminals or connectors	• GO to Pinpoint Test J.
• Battery Saver - System Off displays in centerstack infotainment display	• Normal operation • Audio system • Battery • BCM • Fuses or Fusible Links • Generator • Wiring, terminals or connectors	• GO to Pinpoint Test J.