

Battery and Cables



Vehicles are equipped with a 12-volt, maintenance-free battery.

The battery and cable system consists of the following components:

- Battery
- Battery cable assembly
- Battery tray
- Battery current sensor
- Generator current sensor

For additional information about the the battery and generator current sensors, refer to Section 414-00.

The battery is a 12V DC source connected in a negative ground system. The battery case is sealed with 2 vent holes to release gases. The battery has 3 major functions:

- Engine cranking power source
- Voltage stabilizer for the electrical system
- Temporary power source when electrical loads exceed the generator output current

Ford Motor Company strongly recommends that lead-acid batteries be returned to an authorized recycling facility for disposal.



A0003971