

# Audio Control Module (ACM) Self-Diagnostic Mode



**NOTE:** If the Audio Front Control Module (ACM) , *FCIM* , or *FDIM* are inoperative (blank or do not power on), obtain the *ACM* part number by referencing the label attached to the Audio Front Control Module (ACM) chassis.

1. Turn the *ACM* on.
2. Operate the audio system in radio tuner AM/FM mode.
3. Press and hold preset buttons 3 and 6 for 3 seconds until the speaker walk around test begins.
  - The display indicates each speaker as it is tested.
4. **NOTE:** If the speaker walk around test is the only test required, this procedure can be stopped after Step 3 by turning the *ACM* off.

Before the speaker walk around test is complete, the following actions can be performed:

| Preset Button Press | Diagnostic Function             | Display                                    | Diagnostic Function Description                                                                                                                                                                                                                                                                                                                                                                         |
|---------------------|---------------------------------|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                   | <i>ACM</i> Self-Test            | SELF TEST, SELF PASS, SELF FAIL            | The <i>ACM</i> carries out a self-test. At the end of the self-test, the <i>FDIM</i> display indicates either SELF PASS, or SELF FAIL. If the self-test failed, DTCs can be accessed by pressing the TUNE UP button.                                                                                                                                                                                    |
| 2                   | View DTCs                       | NO DTCS, DTCS FOUND                        | The <i>FDIM</i> displays DTCS FOUND if DTCs are present. To scroll through the DTCs, press the TUNE UP button. If no DTCs are present, the <i>FDIM</i> displays NO DTCS. To clear DTCs, press the EJECT, then TUNE UP button.                                                                                                                                                                           |
| 3                   | AM/FM Antenna Signal Strength   | SIGNAL ###                                 | The <i>FDIM</i> displays the AM/FM antenna signal strength. To see the AM signal strength, the audio system must be in AM radio tuner mode before entering the <i>ACM</i> self-diagnostic mode. To see the FM signal strength, the audio system must be in FM radio tuner mode before entering the <i>ACM</i> self-diagnostic mode. If no antenna is present, a signal strength of 0 will be displayed. |
| 4                   | Software Levels                 | SOFT LEVELS                                | The <i>FDIM</i> displays software levels for various components of the audio system. Knowing the software levels may aid diagnostics. Press the TUNE UP button to scroll through the software levels.                                                                                                                                                                                                   |
| 5                   | Display Test                    | DISPLAY TEST, then all segments illuminate | All of the <i>FDIM</i> display segments illuminate.                                                                                                                                                                                                                                                                                                                                                     |
| 6                   | Retrieve <i>ACM</i> Part Number | RADIO CONFIG                               | The <i>FDIM</i> displays the <i>ACM</i> part number and various configuration levels. Press the TUNE UP button to scroll to the desired function.                                                                                                                                                                                                                                                       |

5. To exit the self-diagnostic mode, turn the *ACM* off.