

Diagnostic Trouble Code (DTC) Chart



Body Control Module (BCM) DTC Chart

DTC	Description	Action
B1115:11	High Mounted Stop Lamp Control: Circuit Short To Ground	GO to Pinpoint Test J.
B123A:11	Left Front Turn Indicator: Circuit Short To Ground	GO to Pinpoint Test M.
B123A:15	Left Front Turn Indicator: Circuit Short To Battery or Open	GO to Pinpoint Test M.
B123B:11	Right Front Turn Indicator: Circuit Short To Ground	GO to Pinpoint Test M.
B123B:15	Right Front Turn Indicator: Circuit Short To Battery or Open	GO to Pinpoint Test M.
B1247:15	Left Rear Turn Indicator: Circuit Short To Battery or Open	This DTC is not supported by this vehicle. Non-supported DTCs can set due to an improperly programmed module. CARRY OUT P.M.I. on the Body Control Module (BCM) . REFER to Section 418-01.
B1248:15	Right Rear Turn Indicator: Circuit Short To Battery or Open	This DTC is not supported by this vehicle. Non-supported DTCs can set due to an improperly programmed module. CARRY OUT P.M.I. on the Body Control Module (BCM) . REFER to Section 418-01.
B1277:11	Reverse Lamp: Circuit Short To Ground	GO to Pinpoint Test U.
B1277:15	Reverse Lamp: Circuit Short To Battery or Open	If the reverse lamps are inoperative, GO to Pinpoint Test U. If the reverse lamps are always on, GO to Pinpoint Test W.
B130C:12	Load Shed Control: Circuit Short To Battery	GO to Pinpoint Test AC.
B130C:14	Load Shed Control: Circuit Short To Ground or Open	GO to Pinpoint Test AC.
B132B:11	Left Stop/Turn Lamp: Circuit Short To	GO to Pinpoint Test J.

DTC	Description	Action
	Ground	
B132B:15	Left Stop/Turn Lamp: Circuit Short To Battery or Open	If the stoplamp is inoperative, GO to Pinpoint Test J. If the stoplamp is always on, GO to Pinpoint Test K.
B132C:11	Right Stop/Turn Lamp: Circuit Short To Ground	GO to Pinpoint Test J.
B132C:15	Right Stop/Turn Lamp: Circuit Short To Battery or Open	If the stoplamp is inoperative, GO to Pinpoint Test J. If the stoplamp is always on, GO to Pinpoint Test K.
B1A85:11	Ambient Light Sensor: Circuit Short To Ground	GO to Pinpoint Test H.
B1A85:13	Ambient Light Sensor: Circuit Open	GO to Pinpoint Test H.
B1C98:11	Left Corner Lamp Circuit: Circuit Short To Ground	GO to Pinpoint Test M.
B1C99:11	Right Corner Lamp Circuit: Circuit Short To Ground	GO to Pinpoint Test M.
B1D00:11	Left Low Beam: Circuit Short To Ground	GO to Pinpoint Test A.
B1D01:11	Right Low Beam: Circuit Short To Ground	GO to Pinpoint Test A.
B1D02:11	Left High Beam Circuit: Circuit Short To Ground	GO to Pinpoint Test B.
B1D02:15	Left High Beam Circuit: Circuit Short To Battery or Open	If the high beam is inoperative, GO to Pinpoint Test B. If the high beam is always on, GO to Pinpoint Test D.
B1D03:11	Right High Beam Circuit: Circuit Short To Ground	GO to Pinpoint Test B.
B1D03:15	Right High Beam Circuit: Circuit Short To Battery or Open	If the high beam is inoperative, GO to Pinpoint Test B. If the high beam is always on, GO to Pinpoint Test D.
B1D35:11	Hazard Switch: Circuit Short To Ground	GO to Pinpoint Test N.
C0040:12	Brake Pedal Switch "A": Circuit Short To Battery	GO to Pinpoint Test K.
U1000:00	Solid State Driver Protection Active - Driver Disabled: No Sub Type Information	The module has temporarily disabled an output because an excessive current draw exists (such as a short to ground). The BCM cannot enable the output until the cause of the short is corrected. ADDRESS all other DTCs first. After the cause of the concern is corrected, CLEAR the DTCs. REPEAT the self-test.

DTC	Description	Action
U3000:49	Control Module: Internal Electronic Failure	The module has permanently disabled an output because an excessive current draw fault (such as a short to ground) has exceeded the limits that the BCM can withstand. The cause of the excessive current draw MUST be corrected before a new BCM is installed. ADDRESS all other DTCs first. After the cause of the concern is corrected, INSTALL a new BCM. Refer to the appropriate Removal and Installation procedure in Section 419-10. . TEST the system for normal operation.
All other DTCs	—	REFER to the Diagnostic Trouble Code (DTC) Chart in Section 419-10.

Steering Column Control Module (SCCM) DTC Chart

DTC	Description	Action
B1007:09	High-Beam Headlamp Switch: Component Failure	INSTALL a new multifunction switch. REFER to Section 211-05. TEST the system for normal operation. If the concern still exists, INSTALL a new SCCM . REFER to Section 211-05. TEST the system for normal operation.
B10A6:09	Main Light Switch: Component Failure	GO to Pinpoint Test C.
B1D36:09	Turn Indicator Switch: Component Failure	If the turn lamp function is inoperative, GO to Pinpoint Test L. If the turn lamp function is always on, INSTALL a new multifunction switch. REFER to Section 211-05. TEST the system for normal operation. If the concern still exists, INSTALL a new SCCM . REFER to Section 211-05. TEST the system for normal operation.
All other DTCs	—	REFER to the Diagnostic Trouble Code (DTC) Chart in Section 419-10.