

Fender Splash Shield



Removal and Installation

Both splash shields

1. If equipped, remove the fender moulding. For additional information, refer to Section 501-08.
2. Remove the wheel and tire. For additional information, refer to Section 204-04

LH splash shield

3. Open the hood and remove the 5 wiring harness pushpins attached to the splash shield in the engine compartment.
4. Remove the 3 splash shield pushpins and the 5 splash shield screws.
5. Partially lower the splash shield and remove the 2 air box deflector pushpins from the engine side of the splash shield.

RH splash shield

6. Open the hood and remove the 4 wiring harness pushpins attached to the splash shield in the engine compartment.
7. Remove the 3 splash shield pushpins and the 5 splash shield screws.

Both splash shields

8. Remove the splash shield.
9. To install, reverse the removal procedure.