

Exterior Mirror Motor



Removal and Installation

NOTE: *The power folding mirrors may need to be synchronized anytime the mirrors are folded or unfolded without using the exterior mirror control switch, or if a new power folding mirror is installed. For additional information, refer to Exterior Mirror Motor Synchronization — Power Folding in this section.*

1. Remove the exterior rear view mirror glass. For additional information, refer to Exterior Mirror Glass — Aero or Exterior Mirror Glass — Trailer Tow in this section.
2. Remove the 3 exterior rear view mirror motor screws.
3. Disconnect the exterior rear view mirror motor electrical connectors.
4. Remove the exterior rear view mirror motor.
5. To install, reverse the removal procedure.
 - If equipped, synchronize the power folding mirrors. For additional information, refer to Exterior Mirror Motor Synchronization — Power Folding in this section.