

Seat Cushion — Rear, CrewCab



Disassembly

NOTE: *For parts identification and location, refer to Seat — Exploded View, Rear, Crew Cab.*

1. Remove the seat cushion latch. Refer to Seat Latch — Rear, Crew Cab.
2. Remove the cushion foam pad.
 - If equipped, disconnect the cushion heater mat electrical connector.
 - Note the wire harness routing for correct installation.
3. Remove the bolt and safety belt buckle.
 - To install, tighten to 32 Nm (24 lb-ft).
4. Remove the screw and inboard side shield.
5. Remove the inboard pivot bolt, inboard pedestal and cushion.
 - To install, tighten to 32 Nm (24 lb-ft).
6. To assemble, reverse the disassembly procedure.