

Seat Cushion — Rear, SuperCab



Disassembly

NOTE: *For parts identification and location, refer to Seat — Exploded View, Rear, SuperCab in this section.*

1. Remove the rear seat cushion cover(s). For additional information, refer to Seat Cushion Cover — Rear, SuperCab in this section.
2. Remove the seat cushion latch. For additional information, refer to Seat Latch — Rear, SuperCab in this section.
3. Remove the riser rear screw and inboard riser from the rear seat frame.
 - To install, tighten to 6 Nm (53 lb-in).
4. Remove the 2 screws and 2 backrest latches from the rear seat frame.
5. To assemble, reverse the disassembly procedure.