

Memory Position Programming



Programming Memory Positions

NOTE: *Memory positions can be stored at any time.*

NOTE: *Verify good battery condition before diagnosing the memory seat system. Poor battery condition may interfere with memory seat operation, even if vehicle starting is possible.*

1. Place the vehicle ignition to ON.

2. **NOTE:** *To program the Remote Keyless Entry (RKE) transmitter, refer to Remote Keyless Entry (RKE) Transmitter Programming and Remote Memory Activation in the General Procedures portion of Section 501-14.*

To set memory position(s), move the memory driver seat, memory exterior mirrors (if equipped), memory adjustable pedals (if equipped) and memory tilt steering column (if equipped) to the preferred position using the appropriate switch(es).

3. **NOTE:** *Activation of the driver seat control switch, adjustable pedal control switch (if equipped), exterior mirror control switch (if equipped) or power tilt steering column switch (if equipped) during memory programming will abort the operation.*

NOTE: *If other tones or chimes are being produced, the memory save tone will not be heard because it is one of the lowest priorities.*

Press and hold a memory button (1 or 2) until a tone is heard (1.5 seconds). When the tone is heard, the memory programming is complete.

4. Repeat the previous steps to program another memory position.

Recalling a Stored Memory Position

NOTE: *A memory recall can be initiated only if the vehicle is in PARK or NEUTRAL and the ignition is not in START. A memory recall in progress will not be affected by moving the ignition switch to START or by moving the gearshift lever out of PARK or NEUTRAL.*

NOTE: *Input from the driver seat control switch, memory SET switch, adjustable pedal control switch, exterior mirror control switch or power tilt steering column switch during a memory recall will abort the memory recall.*

1. The driver can recall the desired memory driver seat, memory exterior mirror (if equipped), memory adjustable pedal (if equipped) and memory tilt steering column (if equipped) positions by depressing either memory SET switch button 1 or 2. Depressing memory SET switch button 1 will initiate a recall of the positions stored for Memory 1. Depressing memory SET switch button 2 will initiate a recall of the positions stored for Memory 2.