


Driver Seat Module (DSM)

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	—	Driver Seat Module (DSM) screws (2 required) (part of 14C708)
2	—	DSM electrical connectors (part of 14C719)
3	14C708 14C708	DSM

Removal and Installation

1. **NOTE:** This step is only necessary when installing a new component.

NOTE: The PMI process must begin with the current DSM installed. If the current DSM does not respond to the diagnostic scan tool, the tool may prompt for As-Build Data as part of the repair.

Using a diagnostic scan tool, begin the PMI process for the DSM following the onscreen instructions.

2. **WARNING:** Turn the ignition OFF and wait one minute to deplete the backup power supply. Ignition must remain OFF until repair is complete. Failure to follow this instruction may result in serious personal injury or death in the event of an accidental deployment.

Turn key off, wait one minute.

3. Move the seat back and up to access the DSM .



4. Remove the 2 screws.

- To install, tighten to 7 Nm (62 lb-in).

5. Disconnect the electrical connectors and remove the **DSM** .

6. To install, reverse the removal procedure.

7. **NOTE:** *This step is only necessary when installing a new component.*

Using a diagnostic scan tool, complete the PMI process for the **DSM** following the on-screen instructions.

8. **NOTE:** *This step is only necessary when installing a new component.*

Operate the driver seat, column and pedals through the full range of travel to register stop positions.