

Lumbar Assembly — Power



Removal and Installation

NOTE: *For parts identification and location, refer to Seat — Exploded View, Front in this section.*

1. Release the backrest cover J-clip and unzip the 2 zippers.
2. If equipped, remove the backrest Thermo-Electric Device (TED) . For additional information, refer to Seat Backrest Thermo-Electric Device in this section.
3. Disconnect the lumbar motor electrical connector.
4. Remove the lumbar assembly.
 - Pinch the lumbar retainers together to release from the backrest frame.
 - For installation, make sure the arrow is pointed up.
5. To install, reverse the removal procedure.