

Seat Backrest Cover — Front, Center



Removal and Installation

NOTE: *The seat backrest cover on a backrest equipped with storage tray is not serviceable separately. A new backrest must be installed. For additional information, refer to Seat Backrest — Front, Center in this section.*

NOTE: *For parts identification and location, refer to Seat — Exploded View, Front, Center in this section.*

1. Remove the seat backrest. For additional information, refer to Seat Backrest — Front, Center in this section.
2. Un-tuck the zipper and open the backrest cover.
3. Invert the backrest cover and remove the hog rings.
4. Remove the backrest cover.
5. To install, reverse the removal procedure.