

Seat Backrest — Front, Center



Removal and Installation

NOTE: For parts identification and location, refer to *Seat — Exploded View, Front, Center* in this section.

1. Remove the seat. For additional information, refer to *Seat — Front, Center* in this section.
2. Remove the rear cupholder.
 - Remove the 2 rear cupholder screws.
 - If equipped, disconnect the power point electrical connector.
3. Remove the LH side shield.
 - Remove the 2 LH side shield screws.
 - Release the pin-type retainer.
4. Remove the backrest latch cover.
5. Remove the backrest stop bolt.
 - To install, tighten to 18 Nm (159 lb-in).
6. Remove the backrest pivot bolt.
 - To install, tighten to 45 Nm (33 lb-ft).
7. Remove the safety belt anchor bolt.
 - To install, tighten to 45 Nm (33 lb-ft).
8. Remove the 2 backrest latch upper bolts and backrest.
 - To install, tighten to 60 Nm (44 lb-ft).
9. **NOTE:** Before installation, make sure the safety belt webbing is not twisted and the safety belts and buckles are accessible to the occupants.

To install, reverse the removal procedure.