

Seat Backrest — Rear, Crew Cab



Removal and Installation

NOTE: *For parts identification and location, refer to Seat — Exploded View, Rear, Crew Cab in this section.*

1. Remove the seat. For additional information, refer to Seat — Rear, Crew Cab, 40 Percent or Seat — Rear, Crew Cab, 60 Percent in this section.
2. Remove the 2 screws and inboard side shield.
3. Remove the screw and outboard side shield.
 - If detached, return the retainer clip to the side shield before installation.
4. If equipped, disconnect the cushion heater mat electrical connector.
5. Remove the 2 backrest pivot bolts and backrest.
 - To install, tighten to 25 Nm (18 lb-ft).
6. To install, reverse the installation procedure.