

Seat Control Switch



Removal and Installation

NOTE: *For parts identification and location, refer to Seat — Exploded View, Front in this section.*

1. If equipped, remove the adjustable lumbar knob.
 - Adjust the lumbar until fully relaxed.
 - Release the retainer and remove the knob.
2. Remove the side shield insert.
 - Release the lower retainers and lift to release the upper retainers.
 - Disconnect the seat control switch electrical connector.
 - If equipped, disconnect the memory SET switch electrical connector.
3. Remove the seat control switch button.
4. If equipped, remove the recliner switch button.
5. Release the retaining tabs and remove switch.
6. To install, reverse the removal procedure.