

Seat Cushion Cover — Front, Center



Removal and Installation

NOTE: For parts identification and location, refer to *Seat — Exploded View, Front, Center* in this section.

1. Remove the seat. For additional information, refer to *Seat — Front, Center* in this section.
2. Remove the rear cupholder.
 - Remove the 2 rear cupholder screws.
 - If equipped, disconnect the power point electrical connector.
3. Remove the RH side shield.
 - Release the pin-type retainer.
4. Remove the LH side shield.
 - Remove the 2 LH side shield screws.
 - Release the pin-type retainer.
5. Remove the 2 cushion pivot bolts and cushion assembly.
 - To install, tighten to 35 Nm (26 lb-ft).
6. Remove the 2 cushion release handle screws and cushion release handle.
7. **NOTICE:** Use care when separating the seat cushion cover from the hook-and-loop strip, or the hook-and-loop strip can be torn from the cushion foam pad.

Release the J-clip, invert the cushion cover and remove.
8. To install, reverse the removal procedure.