

Seat Latch — Front, Center



Removal and Installation

NOTE: For parts identification and location, refer to *Seat — Exploded View, Front, Center* in this section.

1. Remove the seat. For additional information, refer to *Seat — Front, Center* in this section.
2. Remove the rear cupholder.
 - Remove the 2 rear cupholder screws.
 - If equipped, disconnect the power point electrical connector.
3. Remove the backrest latch cover.
4. Remove the RH side shield.
 - Release the pin-type retainer.
5. Remove the 2 backrest latch upper bolts.
 - Lower the backrest to avoid damaging the pivot side.
 - To install, tighten to 60 Nm (44 lb-ft).
6. Remove the 2 backrest latch lower bolts and backrest latch.
 - To install, tighten to 45 Nm (33 lb-ft).
7. To install, reverse the removal procedure.