

Seat Latch — Rear, SuperCab



Removal and Installation

NOTE: 40 percent and 60 percent rear seat cushion latches are removed in the same manor.

NOTE: For parts identification and location, refer to *Seat — Exploded View, Rear, SuperCab* in this section.

1. Remove the rear seat. For additional information, refer to *Seat — Rear, SuperCab* in this section.
2. Remove the cushion pivot bolt.
 - To install, tighten to 33 Nm (24 lb-ft).
3. Remove the rear screw from the outboard riser.
 - Separate the cushion from the inboard riser to avoid pivot bushing damage.
 - To install, tighten to 6 Nm (53 lb-in).
4. Remove the rear latch bolt and outboard seat riser.
 - To install, tighten to 24 Nm (18 lb-ft).
5. Remove the screw and latch bolt cover.
6. Remove the front latch bolt and cushion latch.
 - To install, tighten to 32 Nm (24 lb-ft).
7. To install, reverse the removal procedure.