

Seat Track



Removal and Installation

NOTE: For parts identification and location, refer to *Seat — Exploded View, Front*

NOTE: Removal steps in this procedure may contain install details.

1. Remove the seat backrest. Refer to *Seat Backrest — Front*.
2. Remove the seat cushion cover. Refer to *Seat Cushion Cover — Front*.
3. Remove the 6 pin-type retainers, front inboard, rear inboard and outboard seat track covers.
4. Remove the bolt and safety belt buckle.
 - Disconnect the safety belt buckle electrical connector and detach the wire harness.
 - To install, tighten to 40 Nm (30 lb-ft).
5. If driver seat, remove the seat position sensor. Refer to Section 501-20B.
6. If equipped, remove the **DSM**. Refer to Driver Seat Module (DSM).
7. If equipped, remove the **DCSM**. Refer to Dual Climate Controlled Seat Module (DCSM).
8. If equipped, remove the cushion **TED**. Refer to Seat Cushion Thermo-Electric Device.
9. For passenger seat, remove the **OCSM**. Refer Occupant Classification System Module (OCSM) procedure in Section 501-20B.
10. Disconnect any remaining electrical connectors, detach the wire harness retainers and remove the wire harness. For correct passenger seat wire harness routing, Refer to *Seat Wire Harness Routing*.
11. To install, reverse the removal procedure.
 - If a new seat track has been installed on a driver seat with memory, operate the seat track in all directions through the full range of travel to allow the **DSM** to correctly register seat track stop positions and prevent premature stopping points after repair is complete.
12. If a passenger seat was serviced, carry out the **OCS** System Reset. Refer to the General Procedures portion of Section 501-20B.