

Door Glass Top Run — Front



Removal and Installation

NOTE: *The front window motor must be de-initialized, then initialized whenever the LH front or RH front window motor is removed from the window regulator drum housing, a new window regulator is installed, a new window glass is installed, a new top run is installed or for any operation in which grease or lubricants are applied to the window regulator or glass run.*

1. Remove the front door window glass. For additional information, refer to Window Glass — Front Door in this section.
2. Remove the exterior rear view mirror. For additional information, refer to Section 501-09.
3. Remove the front door outer belt moulding. For additional information, refer to Section 501-08.
4. Remove the front door glass top run.
 - Remove the front door glass top run through the top opening of the front door.
5. To install, reverse the removal procedure.
 - Initialize the front window motor. For additional information, refer to Window Motor Initialization in this section.