

Window Glass — Rear Door, SuperCrew



Removal and Installation

1. Remove the window control switch. For additional information, refer to Window Control Switch — Rear in this section.
2. Remove the rear door trim panel. For additional information, refer to Section 501-05.
3. Remove the rear door mounted speaker. For additional information, Refer to the appropriate section in Group 415 for the procedure.
4. Remove the rear door interior moulding.
5. Position aside the rear door watershield.
6. Temporarily install the window control switch to raise or lower the window as necessary to access the glass-to-regulator assembly bolts.
7. Loosen the rear door window glass-to-regulator assembly bolts.
 - To install, tighten to 11 Nm (97 lb-in).
8. Tape the window in position, then lower the rear door window regulator to the full downward position.
9. Remove the rear door window glass.
 - Pull the rear door window glass out through the top inboard side of the door.
10. To install, reverse the removal procedure.