

Remote Memory Activation



1. Move the driver seat, power mirrors, and adjustable pedals to the desired positions using the associated controls.
2. Press and hold control button 1 for five seconds. A tone will be heard after two seconds confirming memory position has been set. Continue to hold until a second tone is heard after five seconds.
3. Within three seconds press the lock button.
4. Wait 10 seconds, then press the unlock button.
5. Repeat this procedure for memory 2 and another transmitter if desired.