

Remote Memory Deactivation



1. Press the set button on the memory set switch.
2. Within 5 seconds, press any button on the Remote Keyless Entry (RKE) transmitter that you wish to deactivate and then press the set button on the memory set switch.
3. If a second memory setting is desired to be deactivated, repeat the procedure with the second ~~RKE~~ transmitter.