

Stepped Unlock Programming



1. With the ignition switch in the OFF position, press the LOCK and UNLOCK buttons on the Remote Keyless Entry (RKE) transmitter simultaneously for 4 seconds.
 - The turn signals flash twice to indicate the mode change.
2. Repeat Step 1 to enable/disable the stepped unlocking feature.