

Ignition Lock Cylinder — Non Functional



Removal

1. Remove the Passive Anti-Theft System (PATS) transceiver. For additional information, refer to Section 419-01B.
2. Remove the ignition lock cylinder.
 - Use a 1/8-inch diameter drill bit to drill out the lock cylinder retaining pin.
 - Remove and discard the ignition lock cylinder and drill shavings from the steering column.
3. Remove the bearing retainer.
4. Remove the steering column lock housing bearing and steering column lock gear.

Installation

1. Thoroughly clean all drill shavings from the steering column and inspect it for damage.
2. Install a new ignition lock cylinder.
 - Verify the ignition lock cylinder operation.
3. If needed, program the new ~~PATS~~ keys. For additional information, refer to Integrated Keyhead Transmitter (IKT) Key Programming Using Diagnostic Equipment in Section 419-01B.