

Tailgate Latch Remote Control



Removal and Installation

1. If equipped, remove the tailgate step assist handle. For additional information, refer to Section 501-04.
2. Remove the bolts and the tailgate access panel (7 bolts for flareside bed, 8 for without step tailgate, or 13 with step tailgate).
 - To install, tighten to 5 Nm (44 lb-in).
3. Open the 2 clips and release the 2 tailgate latch actuating rods from the tailgate remote control.
4. If equipped, release the tailgate latch actuating rod locator from the tailgate.
5. Remove the 2 tailgate release handle nuts and the tailgate remote control.
 - To install, tighten to 9 Nm (80 lb-in).
6. To install, reverse the removal procedure.