

Roof Opening Panel Frame



Removal and Installation

NOTE: *The roof opening panel motor must be initialized when repairs are carried out on any part of the roof opening panel, including: whenever the roof opening panel motor has been removed from the roof opening panel assembly, a new roof opening panel motor has been installed or when a new roof opening panel frame has been installed. For additional information, refer to Roof Opening Panel Motor Initialization in this section.*

1. Remove the roof opening panel air deflector. For additional information, refer to Air Deflector in this section.
2. Remove the roof opening panel shield. For additional information, refer to Roof Opening Panel Shield in this section.
3. Remove the overhead console. For additional information, refer to Section 501-12.
4. Lower the headliner. For additional information, refer to Section 501-05.
 - Remove the A-pillar, B-pillar and C-pillar (if equipped) trim panels.
 - Remove the LH and RH sun visors and clips.
 - If equipped, remove the 3 headliner pin-type retainers.
 - If equipped, remove the 2 headliner garment hooks.
 - Disconnect the front and rear headliner electrical connectors.

5. **NOTE:** *Make sure the drain hoses are not kinked during installation.*

Disconnect the 2 roof opening panel front drain hoses from the frame.

6. **NOTE:** *Make sure the drain hoses are not kinked during installation.*

Disconnect the 2 roof opening panel rear drain hoses from the frame.

7. Remove the 4 roof opening panel frame-to-B-pillar bolts.
 - To install, tighten to 23 Nm (17 lb-ft).

8. **NOTICE:** **To avoid damage to the roof opening panel frame, be sure to support the frame when removing the mounting bolts.**

Remove the 10 roof opening panel frame mounting bolts.

- To install, tighten to 9 Nm (80 lb-in).

9. Remove the roof opening panel frame.

10. **NOTE:** *If installing a new roof opening panel frame, transfer parts as necessary from the existing roof opening panel assembly.*

To install, reverse the removal procedure.

- Align the roof opening panel. For additional information, refer to Roof Opening Panel Alignment in this section.
- Initialize the roof opening panel motor. For additional information, refer to Roof Opening Panel Motor Initialization in this section.