

Roof Opening Panel Glass



Removal and Installation

NOTE: *The roof opening panel motor must be initialized when repairs are carried out on any part of the roof opening panel, including: whenever the roof opening panel motor has been removed from the roof opening panel assembly, a new roof opening panel motor has been installed or when a new roof opening panel frame has been installed. For additional information, refer to Roof Opening Panel Motor Initialization in this section.*

1. **NOTE:** *The roof opening panel glass must be in the CLOSED position.*

Remove the 4 roof opening panel glass screws.

2. Remove the roof opening panel glass.
3. To install, reverse the removal procedure.
 - Align the roof opening panel. For additional information, refer to Roof Opening Panel Alignment in this section.
 - Initialize the roof opening panel motor. For additional information, refer to Roof Opening Panel Motor Initialization in this section.