

Roof Opening Panel Motor



Removal and Installation

NOTE: *The roof opening panel motor must be initialized when repairs are carried out on any part of the roof opening panel, including: whenever the roof opening panel motor has been removed from the roof opening panel assembly, a new roof opening panel motor has been installed or when a new roof opening panel frame has been installed. For additional information, refer to Roof Opening Panel Motor Initialization in this section.*

1. Lower the rear of the headliner. For additional information, refer to Section 501-05.
 - For SuperCab vehicles, remove the B-pillar trim panels.
 - For SuperCrew vehicles, remove the C-pillar trim panels.
 - If equipped, remove the 3 headliner pin-type retainers.
 - If equipped, remove the 2 headliner garment hooks.
2. Disconnect the roof opening panel motor electrical connector.
3. Remove the 3 roof opening panel motor screws.
 - To install, tighten to 4 Nm (35 lb-in).
4. Remove the roof opening panel motor.
5. To install, reverse the removal procedure.
 - Initialize the roof opening panel motor. For additional information, refer to Roof Opening Panel Motor Initialization in this section.