

Safety Belt Maintenance



WARNING: All seatbelt components must be inspected and corrected as part of any collision repair. Inspect all seatbelt components as prescribed by Seatbelt Procedure After a Collision found in Section 501-20A General Procedures of this manual. Failure to follow this instruction may result in incorrect operation of the seatbelt system and increase the risk of serious personal injury or death in a crash.

1. The safety belt assemblies should be periodically inspected to make sure that they have not become damaged and that they remain in correct operating condition, particularly if they have been subjected to severe stress.
2. Before installing the new safety belt assembly, the safety belt retaining areas must be inspected for damage and distortion. If the retaining points are damaged and distorted, the sheet metal must be reworked back to its original shape and structural integrity.
3. Install the new safety belt(s). Refer to the appropriate procedure(s) in this section. Carry out the appropriate Functional Test Procedure. For additional information, refer to the appropriate Functional Test Procedure in Safety Belt System in this section.