


Safety Belt Shoulder Height Adjuster — SuperCab



NOTE: LH door shown, RH similar.



Item	Part Number	Description
1	25504 25504	Rear door front garnish moulding
2	—	D-ring bolt (part of 612D65)
3	60262 60262	D-ring cover
4	—	Safety belt shoulder height adjuster bolt (part of 602B82)
5	602B82 602B82	Safety belt shoulder height adjuster

Removal and Installation

WARNING: All seatbelt components must be inspected and corrected as part of any collision repair. Inspect all seatbelt components as prescribed by Seatbelt Procedure After a Collision found in Section 501-20A General Procedures of this manual. Failure to follow this instruction may result in incorrect operation of the seatbelt system and increase the risk of serious personal injury or death in a crash.

1. Remove the D-ring cover.
2. Remove the D-ring bolt.
 - To install, tighten to 40 Nm (30 lb-ft).
3. Remove the rear door front garnish moulding.
4. Remove the bolt and safety belt shoulder height adjuster.
 - Rotate the safety belt shoulder height adjuster to remove the lower tab from the sheet metal slot.
 - To install, tighten to 40 Nm (30 lb-ft).
5. **NOTE:** *Before installation, make sure the safety belt webbing is not twisted and the safety belts and buckles are accessible to the occupants.*

To install, reverse the removal procedure.

6. Check the active restraint system for correct operation. For additional information, refer to the appropriate Functional Test procedure in Safety Belt System in this section.