

Inspection and Repair After a Supplemental Restraint System (SRS) Deployment

 [Ford Ecat Electronic Parts Catalog](#)

WARNING: Remove restraint system diagnostic tools from the vehicle prior to road testing. If tools are not removed, the supplemental restraint system (SRS) device may not deploy in a crash. Failure to follow this instruction may result in serious personal injury or death in a crash and possibly violate vehicle safety standards.

NOTE: After diagnosing or repairing a ~~SRS~~, the restraint system diagnostic tools (if required) must be removed before operating the vehicle over the road.

NOTE: Deployable devices (such as air bag modules, pretensioners) may deploy alone or in various combinations depending on the impact event.

NOTE: Always refer to the appropriate workshop manual procedures prior to carrying out vehicle repairs affecting the ~~SRS~~ and safety belt system.

NOTE: The ~~SRS~~ must be fully operational and free of faults before releasing the vehicle to the customer.

All vehicles

1. **NOTE:** Refer to the correct removal and installation procedure for all ~~SRS~~ components being installed.

When any deployable device or combination of devices have deployed and/or the ~~RCM~~ has DTC B1231/B1193:00 (Event Threshold Exceeded) in memory, the repair of the vehicle ~~SRS~~ is to include the removal of all deployed devices and the installation of new deployable devices, the removal and installation of new impact sensors and the removal and installation of a new ~~RCM~~. DTCs must be cleared from all required modules after repairs are carried out.

Vehicles with an ~~OCS~~

2. **NOTE:** After installation of new ~~OCS~~ components, carry out the ~~OCS~~ Reset procedure as instructed in the workshop manual. Refer to the appropriate workshop manual for ~~OCS~~ removal and installation procedure.

When a vehicle has been involved in a collision and the ~~OCSM~~ has DTC B1231/B1193:00 stored in memory, the repair of the ~~OCS~~ is to include the following procedures for the specified system:

- For rail-type ~~OCS~~, inspect the passenger side floorpan for damage and repair as necessary. Install new ~~OCS~~ rails. Do not install a new ~~OCSM~~ unless DTC B1231 cannot be cleared.
- For weight sensor bolt-type ~~OCS~~, inspect the passenger side floorpan for damage and repair as necessary. Install a new seat track with ~~OCS~~ weight sensor bolts. DTC must be cleared from the ~~OCSM~~ before carrying out ~~OCS~~ Reset. Do not install a new ~~OCSM~~ unless DTC B1231/B1193:00 cannot be cleared.
- For bladder-type ~~OCS~~, inspect for damage and repair as necessary. If installation of an ~~OCS~~ component is required, an ~~OCS~~ service kit must be installed.

All vehicles

3. When any damage to the impact sensor mounting points or mounting hardware has occurred, repair or install new mounting points and mounting hardware as needed.
4. When the driver air bag module has deployed, a new clockspring must be installed.
5. New driver and/or front passenger safety belt systems (including retractors, buckles, anchors and height adjusters) must be installed if the vehicle is involved in a collision that results in deployment of the driver and/or front passenger

safety belt pretensioners. For additional information, refer to Section 501-20A.

6. Inspect the entire vehicle for damage, including the following components:

- Steering column (deployable column if equipped)
- Instrument panel knee bolsters and mounting points
- Instrument panel braces and brackets
- Instrument panel and mounting points
- Seats and seat mounting points
- Safety belts, safety belt buckles, safety belt retractors and safety belt anchors. For additional information, refer to Section 501-20A.
- SRS wiring, wiring harnesses and connectors

7. After carrying out the review and inspection of the entire vehicle for damage, repair or install new components as needed.