


Supplemental Restraint System (SRS) Depowering and Repowering

 [Ford Ecat Electronic Parts Catalog](#)

Special Tool(s)

 ST2834-A	Vehicle Communication Module (VCM) and Integrated Diagnostic System (IDS) software with appropriate hardware, or equivalent scan tool
--	---

Depowering Procedure

WARNING: Wear eye and ear protection when servicing a vehicle. Failure to follow this instruction may result in serious personal injury.

WARNING: Never probe the electrical connectors on airbag, Safety Canopy or side air curtain assemblies. Failure to follow this instruction may result in the accidental deployment of these assemblies, which increases the risk of serious personal injury or death.

WARNING: Do not handle, move or change the original horizontal mounting position of the restraints control module (RCM) while the RCM is connected and the ignition switch is ON. Failure to follow this instruction may result in the accidental deployment of the Safety Canopy and cause serious personal injury or death.

WARNING: To reduce the risk of accidental deployment, do not use any memory saver devices. Failure to follow this instruction may result in serious personal injury or death.

NOTE: The air bag warning indicator illuminates when the correct Restraints Control Module (RCM) fuse is removed and the ignition is ON.

NOTE: The Supplemental Restraint System (SRS) must be fully operational and free of faults before releasing the vehicle to the customer.

1. Turn all vehicle accessories OFF.
2. Turn the ignition OFF.
3. At the Body Control Module (BCM) , located below the RH side of the instrument panel, remove the cover and RCM fuse 36 (10A) from the BCM . For additional information, refer to the Wiring Diagrams manual.
4. Turn the ignition ON and monitor the air bag warning indicator for at least 30 seconds. The air bag warning indicator will remain lit continuously (no flashing) if the correct RCM fuse has been removed. If the air bag warning indicator does not remain illuminated continuously, remove the correct RCM fuse before proceeding.
5. Turn the ignition OFF.
6. **WARNING:** Always deplete the backup power supply before repairing or installing any new front or side air bag supplemental restraint system (SRS) component and before servicing, removing, installing, adjusting or striking components near the front or side impact sensors or the restraints control module (RCM). Nearby components include doors, instrument panel, console, door latches, strikers, seats and hood latches. Refer to the

Description and Operation portion of Section 501-20B for location of the RCM and impact sensor(s). To deplete the backup power supply energy, disconnect the battery ground cable and wait at least 1 minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped). Failure to follow these instructions may result in serious personal injury or death in the event of an accidental deployment.

Disconnect the battery ground cable and wait at least one minute. For additional information, refer to Section 414-01.

Repowering Procedure

1. Turn the ignition from OFF to ON.
2. Install ~~RCM~~ fuse 36 (10A) to the ~~BCM~~ and close the cover.
3. **WARNING: Make sure no one is in the vehicle and there is nothing blocking or placed in front of any airbag when the battery is connected. Failure to follow these instructions may result in serious personal injury in the event of an accidental deployment.**

Connect the battery ground cable.

4. Prove out the ~~SRS~~ as follows:
Turn the ignition from ON to OFF. Wait 10 seconds, then turn the ignition back to ON and monitor the air bag warning indicator with the air bag modules installed. The air bag warning indicator will light continuously for approximately 6 seconds and then turn off. If an air bag ~~SRS~~ fault is present, the air bag warning indicator will:
 - fail to light.
 - remain lit continuously.
 - flash at a 5 Hz rate (~~RCM~~ not configured).The air bag warning indicator may not illuminate until approximately 30 seconds after the ignition has been turned from the OFF to the ON position. This is the time required for the ~~RCM~~ to complete the testing of the ~~SRS~~. If the air bag warning indicator is inoperative and a ~~SRS~~ fault exists, a chime will sound in a pattern of 5 sets of 5 beeps. If this occurs, the air bag warning indicator and any ~~SRS~~ fault discovered must be diagnosed and repaired.
Clear all continuous DTCs from the ~~RCM~~ and Occupant Classification System Module (OCSM) using a scan tool.