

Engine Oil Pressure (EOP) Switch



Material

Item	Specification
Motorcraft® Thread Sealant with PTFE TA-24-B	WSK-M2G350-A2

Removal and Installation

1. Disconnect the Engine Oil Pressure (EOP) switch electrical connector.
2. Remove the EOP switch.
 - To install, tighten to 14 Nm (124 lb-in) then an additional 180 degrees.
3. To install, reverse the removal procedure.
 - Apply thread sealant with PTFE to the EOP switch threads prior to installation.